

Product sheet



ARTEOR™ LEGRAND

Roller shutter wireless switch Arteor with Netatmo

REF. 574207 | EAN. 3414971352889

> Visit e-catalogue

Product charateristics

- Up/down/stop function
- LED indicator with low battery warning
- Supplied with a replaceable battery with an 8 year life
- White

Recommendation / Restriction

 To pair your roller shutter wireless switch, you first need to purchase and install a Arteor with Netatmo connected starter pack, as well as one or more Arteor with Netatmo connected roller shutter switches

The product's benefits

Installation

 Extra-slim, the roller shutter wireless switch is attached to a wall with the adhesive pads provided. It can therefore be repositioned. Can also be screwed onto a flush-mounting box

Usage

 Pair as many connected roller shutter switches as you wish and control them all with a single press on your wireless switch

Documentation

TECHNICAL DOCUMENTATION

- F02623EN-01.pdf | PDF (0.44Mo)
- → LE11044AA.pdf | PDF (1.2Mo)

Agreements & Certificates

- Decl. UE RED-A 4144 A | (0.45Mo)
- Decl. UE RED-A 3812 B | (0.25Mo)
- OC / CB-FR_707098 | (0.67Mo)

CATALOGUE PAGE & OTHERS

ex223001_0612.pdf | PDF (0.17Mo)